

Wood spindle machines

Last Issue Date: 14/02/2008		Type Of Service				
		A	B	C	D	E
Activity						
1	<p>ELECTRICAL</p> <ul style="list-style-type: none"> - Inspect for damage to switch gear, wiring and/or conduit. - Check isolator is lockable in off position. - Check operation of start/stop switch. - Check emergency stop where fitted. 				Y	
2	<p>GUARDING</p> <ul style="list-style-type: none"> - Check all guards are secure and function correctly (includes latches locks, fasteners and/or interlocks if fitted). 				Y	
3	<p>FITMENT AND OPERATION</p> <ul style="list-style-type: none"> - Clean machine of all foreign matter. - Check fence angle stops and adjust so that the fence can be indexed for accurate 90 degree cuts. - Zero the pointer for Fence Protractor Scale. - Check and adjust infeed/outfeed table for parallel alignment. - Zero the Pointers for Table Scales. - Check cutters for sharpness/damage, if damaged replace, if dull hone. (New blade to be supplied by site) - Check that cutters are set in appropriate alignment to outfeed table. - Ensure cutting head is free from vibration. - Check that the cutters are securely fastened in the cutter block re-tension set screws and lock nuts if required. - Examine the fence locking and tilt mechanism for correct operation. Check for wear on threads, adjust and repair if required. - Examine drive belts for flaws & correct tension, adjust if necessary, recommend replacement if necessary. - Check tilting Arbour Operation. - Check machine operation. 				Y	
4	<p>DUST EXTRACTION</p> <ul style="list-style-type: none"> - Where equipment is serviced by a ducted dust extraction unit, check condition of hoods, including secure fitment, flexible connections and for obstructions. - If non ducted unit used maintenance covered by ME21. 				Y	
5	Record results in service sheets and log book if included.				Y	

Special Comments and Technical Data

D SERVICE ANNUAL

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.