

Pan Flusher Sanitiser - Malmest Type

Activity		Type Of Service				
		A	B	C	D	E
Last Issue Date: 08/04/2014						
1	Wipe out inside door and chamber with warm water and detergent.	Y	Y	Y		
2	Wipe over outside panels with stainless steel cleaner.	Y	Y	Y		
3	Check for steam or water leaks, tighten unions, hose clamps and glands where necessary.		Y	Y		
4	Check that control box electrical plug is in securely and tighten electrical connections on the contactor.		Y	Y		
5	Remove and clean out sprays and bottle hooks (unscrew from inside chamber) Clean in ultra-sonic cleaner if available if not use a 21 gauge syringe needle. (Keep a spare set of spray domes for immediate changeover.)		Y	Y		
6	Remove top and side panels and front bottom panel.			Y		
7	Remove 3 trays and bottle hooks from inside the chamber, check and clean holes. Replace sprays and bottle hooks.			Y		
8	Start cycle; check operation of hot and cold pumps, anti-syphon tube to test cold water pump first.			Y		
9	Check ball valve operation for hot & cold tanks, hot water level to be 20mm below overflow and cold water level to lower side of swage mark. Clean or replace seal if they do not completely shut off.			Y		
10	Check ball float and replace if necessary.			Y		
11	Tighten screws retaining pan rack in door.			Y		
12	Replace any broken globes in indicator lights.			Y		
13	Clean thermostat probes in hot water tank			Y		
14	Remove and clean brass piston in hot water ball valve. Replace rubber seal, grease plunger with DOW 111 high temperature grease or equivalent.			Y		
15	Clean components.			Y		
16	Top up oil in door damper (use 30 grade)			Y		
17	Operation check - Remove top panel, right hand panel and control box lid. Start cycle. wait until the cold flush is finished, pull back door release solenoid in control box and door lock pins will release. Hold door micro switch and open door with foot panel. Check that sprays are operating correctly.			Y		
18	Record results in log book		Y	Y		

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Special Comments and Technical Data

A SERVICE DAILY (TO BE UNDERTAKEN BY THE SITE)
B SERVICE MONTHLY (INCLUDE ONLY IF REQUIRED BY THE SITE)
C SERVICE 4 OR 6 MONTHLY DEPENDING ON USAGE

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

2 of 3

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.