

Fire Pumpsets (B & C services)

Activity		Type Of Service				
		A	B	C	D	E
Last Issue Date: 07/12/2016						
1	Check pump areas are unobstructed and have adequate lighting.		Y	Y		
2	Check signage and ID plates.		Y	Y		
3	Check pump water supply valves are in open or closed position as required.		Y	Y		
4	Check pressure gauges readings.		Y	Y		
5	Check for visual signs of damage or deterioration.		Y	Y		
6	Check batteries (where present).		Y	Y		
7	Check engine warning devices.		Y	Y		
8	Check that the fuel tank is full. (a) Check and recalibrate the fuel tank gauge to show the correct level. (b) Check and adjust the fuel tank low level warning devices.		Y	Y		
9	Check pump controller: (a) enclosure for corrosion and cleanliness. (b) operation of all visual indicators, switches and sounders. (c) controller status. (d) lights are functional by pressing indicator test button.		Y	Y		
10	Undertake pre-test checks for: (a) safety guards. (b) water supply. (c) for non-electric drive, check: water, oil, belt drives, exhaust condensate drains, cooling water valves correct position and fuel water trap/filter for water contamination. (d) check that all isolating valves are in the correct position. (e) check pressure switches mountings and cleanliness.		Y	Y		
11	Function test for diesel pumps: (a) Start each pumpset by reducing the applied water pressure to the starting device and for compression ignition engines run engine continuously for not less than 10 minutes on the first automatic start and check that the driver achieves full speed within 15 seconds. (b) Restart using manual device. (c) Verify and record cut in pressure is within the required range and that the pump operates at the correct discharge pressure. (d) Check pump gland and drain. (e) Check for abnormal balance condition or noises. (f) Check alarms. (g) Check running speed. (h) Check for water, oil, fuel leaks. (i) Check fittings on ancillary equipment are secure. (j) Check battery charger or generator. (k) Check engine stop mechanism returns to start position automatically. (l) Check belt drives are in good condition. (m) Check battery charger failure alarm.		Y	Y		

Disclaimer - This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Fire Pumpsets (B & C services)

Last Issue Date: 07/12/2016		Type Of Service				
		A	B	C	D	E
Activity						
	(n) Check engine instrumentation and record results. (o) Check flow is evident from the circulation relief valve at pump shut-off head and ceases at the required pressure. (p) Check exhaust system is leak free. (q) Check cooling water is discharging (where applicable).					
12	Function test for electric pumps: (a) Start each pumpset by reducing the applied water pressure to the starting device and run the motor continuously for at least 3 minutes. (b) Restart the pumpset using the manual starting device and run continuously for another 3 minutes. (c) Verify and record cut pressure is within the required range and that pump operates at the correct discharge pressures. (d) Check pump controller status. (e) Check pump glands and drain. (f) Check for abnormal balance condition or noises. (g) Check both local and remote pump alarms and lights.		Y	Y		
13	Controller batteries: (a) Check battery complies with details on identification plate. (b) Check for corrosion, physical damage and security. (c) Check battery enclosure for corrosion and cleanliness. (d) Check float voltage.		Y	Y		
14	After completion of testing procedures return all equipment to the operational condition.		Y	Y		
15	For alternative power-supplies (electric motor-driven pumpset) - if applicable: Run the pump(s) continuously for not less than 3 minutes off the alternative supply.			Y		
16	Hydro-pneumatic accumulator (where fitted): Check the accumulator air pressure.			Y		
17	Record the results in the log book.		Y	Y		

Special Comments and Technical Data

B SERVICE MONTHLY.
C SERVICE 6 MONTHLY.
FOR THE D AND E SERVICES REFER TO TDS F38D.
THIS IS A SPLIT TDS FOR SELECTED SITES ONLY.
SEALED BATTERIES THAT CANNOT BE TOPPED WITH WATER AND ARE ON CONSTANT CHARGE SHOULD NOT BE USED AS THEY MAY EXPLODE.

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.