

Warm water ablut syst - Non recirc to 125l Gas

Activity		Type Of Service				
		A	B	C	D	E
Last Issue Date: 07/12/2020						
1	This TDS excludes activities for thermostatic mixing valves and tempering valves. For these components generic TDS PL39: Thermostatic Mixing Valves and Tempering Valves or PL73: Electronic Thermostatic Mixing Valve are to be scheduled.					
2	Record water storage temperature and ensure it is set at 63 degC. NOTE: Do not increase storage temperature where this can result in scalding temperatures from any outlet, report these systems immediately to the FMSP.		Y	Y	Y	Y
3	Check cleanliness and mechanical condition of system.		Y	Y	Y	Y
4	Check operation of all safety valves and devices.			Y	Y	Y
5	Check unit for damage or leaks.			Y	Y	Y
6	Check condition and operation of hot water service including: - strainer / filter. - ignition system. - pilot light. - gas pressure / flow. - burner operation for correct gas / air mixture to ensure maximum efficiency. - flue, especially for any obstructions and cleanliness.			Y	Y	Y
7	Check safety tray and overflow, if fitted.			Y	Y	Y
8	Measure and record water temperature from outlets. Refer to site system plan to help in locating them. Inform site of any outlet/s where the temperature of the water is inappropriate to its use.			Y	Y	Y
9	Decontaminate fittings by running outlets for 10(5) minutes with water at 60(70) degrees respectively. If volume of water insufficient use chlorine solution as detailed in the Guidelines for the control of Legionella. Refer to site system plan to help in locating them.			Y	Y	Y
10	Obtain 2 water samples from different parts of the system one being the furthest outlet from the water heater and test both samples in a NATA certified laboratory for Total Bacteria and Legionella. (Testing frequency can be increased depending on site requirements).			Y	Y	Y
11	Thoroughly clean system if inspection reveals sludge, slime, scale, foam, rust, dirt dust or other impurities of foreign material present in the system.					Y
12	All outlets that are not used frequently to be flushed weekly at full flow for 20 seconds, and all outlets on individual branches to be flushed out simultaneously. Refer to site system plan to help in locating them.	Y	Y	Y	Y	Y
13	Water leak sensor shut-off valve, if installed: a) Check the condition of the valve, sensor and cabling. b) Test the valve in accordance with the manufacturer's instructions. c) Check the visual and/or audible alarms as applicable.			Y	Y	Y
14	Water leak sensor shut-off valve, if installed: Replace the batteries annually or when			Y	Y	Y

Disclaimer - This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Warm water ablut syst - Non recirc to 125l Gas

Last Issue Date: 07/12/2020		Type Of Service				
		A	B	C	D	E
Activity						
	the 'Replace the batteries' alarm is activated (if applicable).					
15	For larger units (to 125 litres) replace the sacrificial anode at the first replacement interval only (generally 4 - 7 years as recommended by the manufacturer / required). With a permanent marker write the date on the external casing of the heater.					Y
16	Note: The FMSP to arrange an independent audit of the system. (For audit scope refer to the SA Health Warm water system Legionella Regulations compliance inspection report form.)				Y	Y
17	Record all the results in the logbook and submit a customer report to the FMSP.	Y	Y	Y	Y	Y

Special Comments and Technical Data

A WEEKLY (MAY BE UNDERTAKEN BY SITE).

B SERVICE MONTHLY.

C SERVICE 6 MONTHLY.

D SERVICE ANNUAL.

E SERVICE:

- ANODE REPLACEMENT.

- CLEANING TO BE UNDERTAKEN WHEN REQUIRED AND TO BE COSTED SEPARATELY.

THIS TDS EXCLUDES ACTIVITIES FOR THERMOSTATIC MIXING VALVES AND TEMPERING VALVES. FOR THE MAINTENANCE OF THEM REFER TO GENERIC TDS PL39: THERMOSTATIC MIXING VALVES AND TEMPERING VALVES OR PL73: ELECTRONIC THERMOSTATIC MIXING VALVE ONE OF WHICH MUST BE SCHEDULED IN CONJUNCTION WITH THIS TDS PL06RW.

SERVICE ACTIVITIES AND FREQUENCIES MAY VARY DEPENDING ON MANUFACTURER'S REQUIREMENTS AND SITE CONDITIONS INCLUDING WATER QUALITY.

NOTE ANY REQUIRED REMEDIAL WORK ON THE CUSTOMER SERVICE REPORT AND NOTIFY THE FMSP. INFORM THE FMSP IF THE SYSTEM HAS A CIRCULATING PUMP.

- FOR THE ANNUAL INSPECTION (INDEPENDENT AUDIT) OF THE SYSTEM USE PL72.

- FOR THE REGISTRATION OF THE SYSTEM USE PL56.

APPLICABLE LEGISLATION, STANDARDS AND GUIDELINES:

PUBLIC HEALTH (LEGIONELLA) REGULATIONS, THE OTR AND SA HEALTH, THE GUIDELINES FOR THE CONTROL OF LEGIONELLA (SA HEALTH) and enHEALTH GUIDELINES FOR LEGIONELLA CONTROL. AS3666.2, AS3666.3, SAA/SNZ HB32, AS3896, AS4276.3.2, AS3500.1 & AS3500.4

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.