

Steam Boiler - Electric Powered

Last Issue Date: 14/06/2018		Type Of Service				
		A	B	C	D	E
Activity		A	B	C	D	E
1	a) Remove water level devices, disassemble, check chambers and valves. b) Reassemble and check operation.				Y	
2	Check condition and operation of any fan and airflow interlocks.				Y	
3	Check condition and operation of all safety valves.				Y	
4	Check condition and operation of start fire interlock.				Y	
5	Check condition and operation of steam pressure interlock.				Y	
6	Check and clean water filters (where fitted).				Y	
7	Check the quality of feedwater and boiler water.				Y	
8	Check feedwater pump, especially for: a) Operating pressure. b) Condition and signs of wear.				Y	
9	Check condition and operation of all controls, including all electrical equipment and wiring.				Y	
10	Confirm that the boiler alarms are going out to the service personnel via the paging system or other as applicable.				Y	
11	Check condition and operation of all instruments.				Y	
12	Check condition of heating elements.				Y	
13	Clean and examine the boiler internally for scale, corrosion & defects.				Y	
14	Start up and check all components for: a) Correct operation and sequence. b) Leaks or loose connections. c) Correct calibration and adjustment.				Y	
15	Provide written report on condition and operation.				Y	
16	Record all results in the logbook.				Y	

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Special Comments and Technical Data

D SERVICE ANNUAL - MAX. (FOR ALL ELECTRIC BOILERS WITH AN ELEMENT THAT FAILS ON LOW WATER OR FOR ELECTRIC BOILERS WITH AN ELEMENT THAT MAY NOT FAIL ON LOW WATER WITH MAX. POWER OUTPUT OF 250KW & MAX. DESIGN PRESSURE OF 2.5MPA). USE ME171A FOR THE REGISTRATION (THIS IS 5 YEARLY) USE ME238 FOR THE ANNUAL INDEPENDENT INSPECTION. SERVICE ACTIVITIES AND FREQUENCIES MAY VARY DEPENDING ON SITE REQUIREMENTS AND MANUFACTURER'S RECOMMENDATIONS. SERVICING TO BE DONE IN ACCORDANCE WITH AS1228, AS2593 AND AS3788 AND AS3873. AS2593, TABLE 1 PROVIDES MAINTENANCE PARAMETERS.

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

2 of 3

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.