

Safety Electronic Control (LogiCamms) System

Last Issue Date: 29/05/2019		Type Of Service				
		A	B	C	D	E
Activity		A	B	C	D	E
1	Obtain a monthly service fee from the sub-contractor.	Y		Y	Y	
2	Undertake the following Functional Checks in accordance with the manufacturer's written instructions:			Y	Y	
3	Graffiti Wash Facility (GWF): a) Check the Human Machine Interface (HMI) alarm logs; b) Check the condition of control panels, operator controls and signalling devices; c) Check the operation of warning lights and sirens using the panel stop button and verify current monitor HMI alarms (Refer to manufacturer's manual schematics 19, 21 and 34); d) Check the operation of traffic lights, warning lights and sirens using the panel test button; e) Check the internal and external traffic lights amber and red function using the 'Hold' sequence; and f) Check high pressure water system enable/disable function using the access key exchange and water pressure switch operation.			Y	Y	
4	Commissioning Facility (CF) Main Panel (South): Check the HMI alarm logs.			Y	Y	
5	CF: Check the condition of control panels, operator controls and signalling devices.			Y	Y	
6	CF Main Panel (South): a) Verify the Programmable Logic Controller (PLC) healthy indications then check failure scenarios, reset function and HMI alarms for: power failure (Q1101), rack failure (Q1105), and module failure (Q1202); and b) Check the operation of warning lights and sirens using the panel stop button.			Y	Y	
7	CF Remote Input Output (RIO) Panel (North): Check the operation of warning lights and sirens using the panel stop button.			Y	Y	
8	CF East Road (CFE): a) Verify the signals and derailer functionality using the 'North Entry' and 'South Entry' sequences with 'Release' selected at the road lockout switch; b) Check the operation of warning lights and sirens using each of the six pit stop buttons in turn; c) Verify the current monitor HMI alarms (schematics 16 and 19); and d) Verify signal functionality for road lockout, end doors, overhead gates, platform gates and road access key operations.			Y	Y	
9	CF West Road (CFW): a) Verify the signals and derailer functionality using the 'North Entry' and 'South Entry' sequences with 'Release' selected at the road lockout switch; b) Verify signal functionality for road lockout, end doors and road access key operations; and c) Verify current monitor HMI alarms (schematics 17 and 19).			Y	Y	
10	Electrical Control Panels: Clean the GWF Panel, CF Main Panel and				Y	

Disclaimer - This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Safety Electronic Control (LogiCamms) System

Last Issue Date: 29/05/2019		Type Of Service				
		A	B	C	D	E
Activity						
	CF RIO Panels.					
11	Record the results in the log book or email the test sheets to the facility manager.	Y		Y	Y	

Special Comments and Technical Data

A SERVICE MONTHLY / C SERVICE 6 MONTHLY
 D SERVICE ANNUAL
 GWF = GRAFFITI WASH FACILITY (LIVE ROAD, REQUIRES NETWORK ACCESS APPLICATION)
 BEFORE ANY TESTS ARE CARRIED OUT NOTIFY (BOMBARDIER) SITE REPRESENTATIVE.
 MAINTENANCE IS TO COMPLY WITH THE MANUFACTURER'S RECOMMENDATIONS. REFER TO THE MANUAL FOR ADDITIONAL INFORMATION.
 NOTE:
 THIS SERVICE IS SITE SPECIFIC - SEAFORD RAIL DEPOT.
 THE MONTHLY A SERVICE IS ONLY TO BE SCHEDULED AT SITES SELECTED BY THE FACILITY MANAGER AND SITE REPRESENTATIVE.
 (THE GENERIC SERVICE FREQUENCIES ARE 6 MONTHLY AND ANNUAL).

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
 Department of Planning,
 Transport and Infrastructure

Download Date: 22/12/2020

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.