

Air Compressor - Generic Type

Activity		Type Of Service				
		A	B	C	D	E
Last Issue Date: 11/10/2017						
1	Check the oil level in the sump, adjust if required. - Use SAE motor oil only and do not overfill.		Y	Y	Y	
2	Check receiver pressure and pressure reducer output pressures.		Y	Y	Y	
3	Check condensate drain from air receiver and filters.		Y	Y	Y	
4	Check condition and tension of the V-belts, where applicable.			Y	Y	
5	Replace the intake air cleaner cartridge and end felts.			Y	Y	
6	Check motor bearings for any undue noise.			Y	Y	
7	ODOR ACTIVATED CARBON FILTER, where applicable. a) Check efficiency of odor removal. - Replace activated carbon when odor becomes noticeable. - Return used carbon to supplier for re-activation. b) Check filters and seals between filter units for leakage. c) Check filter frames for signs of corrosion or damage.			Y	Y	
8	Check condition & operation of refrigerated air dryer, where applicable.			Y	Y	
9	Check condition and operation of all pressure relief valves including actuating the valve to relieve pressure for 10 seconds.			Y	Y	
10	ELECTRICAL Check condition and operation of all electrical components including: a) All safety devices. b) All connections for security, tightness, contact and corrosion. c) Relays and contactors. d) All overloads and circuit breakers. e) All indicator lights. f) Compressor motor including motor current draw at full operating load and compare with rated input. g) Fan motors.			Y	Y	
11	Check cut in/out pressures of compressor/s.				Y	
12	Check condition and operation of all safety devices.				Y	
13	Select existing lag compressor to the lead position, where applicable.				Y	
14	Check and record each compressors "hours-run" readings.				Y	
15	a) Drain oil, clean out sump and refill with new oil. - Use SAE motor oil only and do not overfill. b) Replace the oil and air filters, if necessary.				Y	
16	Check for leaks in oil and air systems.				Y	
17	DESICCANT AIR DRYER (where applicable): Check: a) Cycle operation.				Y	

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 04/11/2021

Air Compressor - Generic Type

Last Issue Date: 11/10/2017		Type Of Service				
Activity		A	B	C	D	E
	b) Exhaust mufflers. c) Desiccant. d) Pre-filters. e) Desiccant filters. f) Clean air purge valves.					
18	Check that registration is current (where applicable). See special comments below.				Y	
19	Record all results in log book.		Y	Y	Y	

Special Comments and Technical Data

B SERVICE MONTHLY IF REQUIRED (BY SITE)
 C SERVICE 6 MONTHLY OR 3 MONTHLY FOR HEAVILY USED COMPRESSOR
 D SERVICE ANNUAL
 FOR RECEIVERS OVER 150MPAL CAPACITY INCLUDE INSPECTION
 (ME240) AND REGISTRATION (ME171)

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
 Department of Planning,
 Transport and Infrastructure

Download Date: 04/11/2021

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.