

Chiller-Cent-Air-cooled-Mag&Evap/C-Bear'g-Powerpax

Activity		Type Of Service				
		A	B	C	D	E
Last Issue Date: 12/07/2018						
1	Check mains power supply voltages.		Y	Y	Y	
2	Check hot spots / discolouration on power cables.		Y	Y	Y	
3	Check amperages are as recommended by manufacturer.		Y	Y	Y	
4	Ensure communication cables are secure.		Y	Y	Y	
5	Check there are no signs of physical damage & discolouration on printed circuit boards.		Y	Y	Y	
6	Check compressor IGV assembly is operating correctly.		Y	Y	Y	
7	Check all mounting bolts are secure.		Y	Y	Y	
8	Check for refrigeration leaks.		Y	Y	Y	
9	Check for mechanical damage.		Y	Y	Y	
10	Check operating temperature and pressure.		Y	Y	Y	
11	Check for insulation damage.		Y	Y	Y	
12	Check chilled water sensors are installed and secure.		Y	Y	Y	
13	Check for even distribution of cooling water flow across pads. If 'dry spotting' then execute activity 27. (Evaporative Condenser).		Y	Y	Y	
14	Ensure electrical terminals are secure.			Y	Y	
15	Ensure pressure and temperature connections are secure.			Y	Y	
16	Check and if necessary clean printed circuit boards.			Y	Y	
17	Check EXV winding resistance without disturbing connections unless repair is required.			Y	Y	
18	Check the compressor fault log. Download any faults and review the Fault Log for any further action required.		Y	Y	Y	
19	Check backplane voltage test points.			Y	Y	
20	Check all modules and connections are secure.			Y	Y	
21	Check that the compressor motor cooling line sight glass is full during operation.			Y	Y	
22	Open ends, Flush and check for free flowing ports in cooling water sparge bars. (Evaporative Condenser).			Y	Y	
23	Check calibration of temperature and pressure sensors.				Y	
24	Check water flow and pressure drops against design values.				Y	
25	Check flow detection system operation, by switching off applicable A/D converter C/B.				Y	
26	Check and clean the water strainers. Remove any biofilm, and clean and check for free movement of the cooling water sump level sensor float.				Y	

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 04/11/2021

Chiller-Cent-Air-cooled-Mag&Evap/C-Bear'g-Powerpax

Last Issue Date: 12/07/2018		Type Of Service				
		A	B	C	D	E
Activity		A	B	C	D	E
27	Flip over (facing side) the water pads to minimise permanent 'bowing'. (Evaporative Condenser).				Y	
28	Hose down the condenser coils to remove any debris.	Y			Y	
29	- Check the EXV & Level Sensor Operation. - Check the level sensor calibration and recalibrate if required.			Y	Y	
30	Check the soft start fan operation. (Note: The manufacturer recommends replacing it every 2 years).			Y	Y	
31	Apply lanoline grease to the bearing feed throughs and the SCR bolts if required.				Y	
32	Check the operation of the chiller running at the highest load possible. (Where site conditions permit).		Y	Y	Y	
33	Check for water leaks.				Y	
34	Record all results in the customer service report/log book.		Y	Y	Y	

Special Comments and Technical Data

B SERVICE MONTHLY
 C SERVICE QUARTERLY
 A SERVICE 6 MONTHLY
 D SERVICE ANNUALLY
 SERVICE ACTIVITIES AND FREQUENCIES MAY VARY DEPENDING ON MANUFACTURER'S REQUIREMENTS AND SITE CONDITIONS.
 THE SERVICING IS TO BE DONE IN ACCORDANCE WITH APPLICABLE STANDARDS.
 THE FULL TITLE FOR THIS TDS IS:
 CHILLER - CENTRALISED, AIR COOLED - MAGNETIC & EVAPORATIVE CONDENSER BEARING POWERPAX.

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
 Department of Planning,
 Transport and Infrastructure

Download Date: 04/11/2021

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.