

Condensing Boiler

Activity		Type Of Service				
		A	B	C	D	E
Last Issue Date: 29/08/2017						
1	Check Boiler for correct operation.			Y	Y	
2	Visually check the flue gas vent pipping and combustion air piping for any signs of blockage, leakage or deterioration.			Y	Y	
3	Inspect the boiler relief valve and the relief valve discharge pipe for signs of weeping or leakage.			Y	Y	
4	Check the condensate drain system (drain line PVC or ABS pipes for blockages). Clean if necessary.			Y	Y	
5	Inspect burner flame (if possible). If flame appearance changes from the norm the corrective action should be taken.			Y	Y	
6	Test low water cut-off to ensure device is working properly. Ensure water levels do not drop below manufacture's recommended levels.			Y	Y	
7	Condensate Neutraliser (if fitted): a) Check the pH level at the outlet of the neutralising kit. Acidity levels must be kept between 5-9. b) Check the pH level after condensate has exited the tank or by removing the lid and taking a sample from the last chamber before the outlet. Acidity levels must be kept between 5-9. Replace the neutralisation media when pH drops below 7. (Replenish the tank with the larger material then sprinkle the smaller pellets on top).			Y	Y	
8	Check and record flow and return water temperatures and pressures.				Y	
9	Inspect gas assembly components.				Y	
10	Inspect safety devices, flow switches for water and gas.				Y	
11	Inspect and clean the combustion chamber and burners.				Y	
12	Inspect and clean flame rod ignitor.				Y	
13	Check the operation of the fan/blower.				Y	
14	Check gas pressure and adjust if necessary.				Y	
15	Inspect and clean the flue exhaust assembly.				Y	
16	Check all water connections and valves.				Y	
17	Carry out combustion analysis and recalibrate if necessary.				Y	
18	Check electrical and electronic components.				Y	
19	Record results in the log book.			Y	Y	

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

Special Comments and Technical Data

C SERVICE 6 MONTHLY

D SERVICE ANNUALLY

DEFAULT ACTIVITIES AND FREQUENCIES FOR BOILERS OF MEDIUM TO HEAVY USE.

SERVICE ACTIVITIES AND FREQUENCIES MAY VARY DEPENDING ON SITE CONDITIONS AND MANUFACTURERS RECOMMENDATIONS.

REFER TO AS3666.2, AS3788, AS3873 AND EPA CODES OF PRACTICE FOR MORE INFORMATION.

REGISTRATION REFER TO TDS ME171A.

INSPECTION REFER TO TDS ME238.

Disclaimer -This TDS is intended to provide guidance only to support Preventative Maintenance servicing activities. All TDS users are encouraged to read and understand the full [Conditions of Use](#) provided on the final page of this document and on the DPTI website.

For more information please contact the applicable Facilities Management Service Provider.



Government of South Australia
Department of Planning,
Transport and Infrastructure

Download Date: 22/12/2020

2 of 3

Conditions of Use

A TDS should be used as a generic guide for Facilities Management Service Providers (FMSP) to deliver Facilities Maintenance Services, specifically Preventative Maintenance in accordance with the DPTI [Agency Work Procedure Manual](#).

Users of a TDS should familiarise themselves with the following **Conditions of Use**:

1. You use the information and data contained in any TDS published by DPTI at your sole risk. DPTI-AGFMA does not have the expertise to provide complete or accurate technical data schedules and provides these technical data sheets merely as a starting point and/or guide.
2. If you rely on the information in a TDS you are responsible for ensuring, by independent verification, its accuracy, currency and completeness. DPTI cannot guarantee that the information contained in a TDS meets the standards or requirements of legislative requirements.
3. A TDS is not an exhaustive list of tasks or obligations that may be required and is generally generic in nature. DPTI does not oblige the user of a TDS to rely on it to the exclusion of other sources of information. For example, manufacturer's requirements may need to be followed for additional and / or alternative tasks and for additional and / or alternative servicing frequencies. You should always check the primary source of information such as the Australian Standards, manufacturer's specifications, legislation and other standards before undertaking any work to which a schedule may apply.
4. You must apply appropriate risk management principles and carry out all tasks in accordance with obligations under the [Work Health and Safety Act 2012](#).
5. You must not use a TDS unless you meet the specific competency requirements for preventative maintenance servicing works and are capable of applying the TDS to your trade or area of expertise. A TDS is only to be used by people who are specifically instructed by DPTI to use them and only for work undertaken in South Australia.
6. DPTI, its agents, instrumentalities, officers and employees make no representations, express or implied, as to the accuracy of the information, the data contained in a TDS or the suitability of a TDS for a particular purpose.
7. DPTI does not provide legal advice. DPTI accepts no liability, howsoever arising, for any loss resulting from the use of a TDS and any information or data or reliance placed on them.
8. DPTI may change information and data in a TDS without notice.
9. DPTI may revise this disclaimer at any time by updating these Conditions of Use.